

52+26 Tone_MRU3_CH64 (5320MHz)



52+26 Tone_MRU3_CH157 (5785MHz)



106+26 Tone_MRU2_CH64 (5320MHz)




106+26 Tone_MRU2_CH157 (5785MHz)



802.11be-EHT80 Power Spectral Density - Ant 6


484+242 Tone_MRU3_CH48 (5210MHz)



484+242 Tone_MRU3_CH64 (5290MHz)



484+242 Tone_MRU3_CH116 (5610MHz)



484+242 Tone_MRU3_CH157 (5775MHz)



802.11be-EHT160 Power Spectral Density - Ant 6

996+484 Tone_MRUI3_CH48 (5250MHz)



996+484 Tone_MRUI3_CH64 (5570MHz)



802.11be-EHT80 Power Spectral Density - Ant 6

484+242 Tone_PUN1_CH42 (5210MHz)



484+242 Tone_PUN1_CH58 (5290MHz)



484+242 Tone_PUN1_CH122 (5610MHz)



484+242 Tone_PUN1_CH155 (5775MHz)



802.11be-EHT160 Power Spectral Density - Ant 6

996+484 Tone_PUN1_CH50 (5250MHz)



996+484 Tone_PUN1_CH114 (5570MHz)



802.11be-EHT160 Power Spectral Density - Ant 6

996+484+242 Tone_PUN2_CH50 (5250MHz)



996+484+242 Tone_PUN2_CH114 (5570MHz)



802.11a Power Spectral Density - Ant 7

Channel 36 (5180MHz)



Channel 40 (5200MHz)



Channel 48 (5240MHz)



Channel 52 (5260MHz)



Channel 60 (5300MHz)



Channel 64 (5320MHz)




Channel 100 (5500MHz)




Channel 116 (5580MHz)





802.11ac-VHT20 Power Spectral Density - Ant 7


Channel 36 (5180MHz)



Channel 40 (5200MHz)



Channel 48 (5240MHz)



Channel 52 (5260MHz)




Channel 60 (5300MHz)



Channel 64 (5320MHz)




Channel 100 (5500MHz)




Channel 116 (5580MHz)





802.11ac-VHT40 Power Spectral Density - Ant 7


Channel 38 (5190MHz)



Channel 46 (5230MHz)




Channel 54 (5270MHz)



Channel 62 (5310MHz)




Channel 102 (5510MHz)




Channel 110 (5550MHz)





802.11ac-VHT80 Power Spectral Density - Ant 7

Channel 42 (5210MHz)



Channel 58 (5290MHz)



Channel 106 (5530MHz)



Channel 122 (5610MHz)



Channel 138 (5690MHz)




Channel 155 (5775MHz)



802.11ac-VHT160 Power Spectral Density - Ant 7

Channel 50 (5250MHz)




Channel 114 (5570MHz)



802.11be-EHT20 Power Spectral Density - Ant 7


Channel 36 (5180MHz)



Channel 40 (5200MHz)




Channel 48 (5240MHz)



Channel 52 (5260MHz)




Channel 60 (5300MHz)




Channel 64 (5320MHz)





802.11be-EHT40 Power Spectral Density - Ant 7


Channel 38 (5190MHz)



Channel 46 (5230MHz)



Channel 54 (5270MHz)



Channel 62 (5310MHz)




Channel 102 (5510MHz)




Channel 110 (5550MHz)





802.11be-EHT80 Power Spectral Density - Ant 7


Channel 42 (5210MHz)




Channel 58 (5290MHz)



Channel 106 (5530MHz)




Channel 122 (5610MHz)



Channel 138 (5690MHz)




Channel 155 (5775MHz)



802.11be-EHT160 Power Spectral Density - Ant 7

Channel 50 (5250MHz)



Channel 114 (5570MHz)



802.11be-EHT20 Power Spectral Density - Ant 7


26 Tone_RU0_CH36 (5180MHz)



26 Tone_RU8_CH48 (5240MHz)



26 Tone_RU8_CH64 (5320MHz)



26 Tone_RU0_CH100 (5500MHz)




26 Tone_RU8_CH116 (5580MHz)



26 Tone_RU8_CH140 (5700MHz)





802.11be-EHT20 Power Spectral Density - Ant 7

52 Tone_RU74_CH36 (5180MHz)



52 Tone_RU77_CH48 (5240MHz)



52 Tone_RU77_CH64 (5320MHz)



52 Tone_RU74_CH100 (5500MHz)




52 Tone_RU77_CH116 (5580MHz)



52 Tone_RU77_CH140 (5700MHz)





802.11be-EHT20 Power Spectral Density - Ant 7


106 Tone_RU106_CH36 (5180MHz)



106 Tone_RU107_CH48 (5240MHz)




106 Tone_RU107_CH64 (5320MHz)



106 Tone_RU106_CH100 (5500MHz)




106 Tone_RU107_CH116 (5580MHz)



106 Tone_RU107_CH140 (5700MHz)





802.11be-EHT20 Power Spectral Density - Ant 7

242 Tone_RU122_CH36 (5180MHz)



242 Tone_RU122_CH48 (5240MHz)



242 Tone_RU122_CH64 (5320MHz)



242 Tone_RU122_CH100 (5500MHz)




242 Tone_RU122_CH116 (5580MHz)



242 Tone_RU122_CH140 (5700MHz)





802.11be-EHT20 Power Spectral Density - Ant 7


52+26 Tone_MR3_CH48 (5240MHz)



52+26 Tone_MR3_CH64 (5320MHz)



52+26 Tone_MR3_CH116 (5580MHz)



52+26 Tone_MR3_CH157 (5785MHz)

