

802.11be-EHT20 - Ant 6

26 Tone_RU0_CH1 (5955MHz)



26 Tone_RU8_CH93 (6415MHz)



26 Tone_RU0_CH97 (6435MHz)



26 Tone_RU8_CH113 (6515MHz)




26 Tone_RU0_CH117 (6535MHz)



26 Tone_RU8_CH181 (6855MHz)



26 Tone_RU0_CH189 (6895MHz)




26 Tone_RU8_CH233 (7115MHz)



802.11be-EHT20 - Ant 6


52 Tone_RU74_CH1 (5955MHz)



52 Tone_RU77_CH93 (6415MHz)




52 Tone_RU74_CH97 (6435MHz)




52 Tone_RU77_CH113 (6515MHz)




52 Tone_RU74_CH117 (6535MHz)



52 Tone_RU77_CH181 (6855MHz)



52 Tone_RU74_CH189 (6895MHz)




52 Tone_RU77_CH233 (7115MHz)



802.11be-EHT20 - Ant 6

106 Tone_RU106_CH1 (5955MHz)



106 Tone_RU107_CH93 (6415MHz)




106 Tone_RU106_CH97 (6435MHz)



106 Tone_RU107_CH113 (6515MHz)



106 Tone_RU106_CH117 (6535MHz)



106 Tone_RU107_CH181 (6855MHz)



106 Tone_RU106_CH189 (6895MHz)




106 Tone_RU107_CH233 (7115MHz)




802.11be-EHT20 - Ant 6


242 Tone_RU122_CH1 (5955MHz)




242 Tone_RU122_CH93 (6415MHz)




242 Tone_RU122_CH97 (6435MHz)




242 Tone_RU122_CH113 (6515MHz)




242 Tone_RU122_CH117 (6535MHz)




242 Tone_RU122_CH181 (6855MHz)



242 Tone_RU122_CH189 (6895MHz)




242 Tone_RU122_CH233 (7115MHz)




802.11be-EHT20 - Ant 6


52+26 Tone_MRU1_CH49 (6195MHz)




52+26 Tone_MRU1_CH105 (6475MHz)



52+26 Tone_MRU1_CH153 (6715MHz)




52+26 Tone_MRU1_CH213 (7015MHz)




802.11be-EHT20 - Ant 6


106+26 Tone_MRU1_CH49 (6195MHz)




106+26 Tone_MRU1_CH105 (6475MHz)



106+26 Tone_MRU1_CH153 (6715MHz)




106+26 Tone_MRU1_CH213 (7015MHz)




802.11be-EHT80 - Ant 6


484+242 Tone_MRU1_CH55 (6225MHz)




484+242 Tone_MRU1_CH103 (6465MHz)



484+242 Tone_MRU1_CH151 (6705MHz)




484+242 Tone_MRU1_CH215 (7025MHz)




802.11be-EHT160 - Ant 6


996+484 Tone_MRU4_CH47 (6185MHz)




996+484 Tone_MRU4_CH111 (6505MHz)



996+484 Tone_MRU4_CH143 (6665MHz)




996+484 Tone_MRU4_CH207 (6985MHz)




802.11be-EHT320 - Ant 6

2x996+484 Tone_MRU4_CH31 (6105MHz)



2x996+484 Tone_MRU4_CH95 (6425MHz)




2x996+484 Tone_MRU3_CH159 (6745MHz)




802.11be-EHT320 - Ant 6


3x996 Tone_MRU2_CH31 (6105MHz)



3x996 Tone_MRU2_CH95 (6425MHz)




3x996 Tone_MRU2_CH159 (6745MHz)




802.11be-EHT320 - Ant 6


3x996+484 Tone_MRU3_CH31 (6105MHz)



3x996+484 Tone_MRU3_CH95 (6425MHz)




3x996+484 Tone_MRU3_CH159 (6745MHz)



802.11be-EHT80 - Ant 6


484+242 Tone_PUN1_CH55 (6225MHz)




484+242 Tone_PUN1_CH103 (6465MHz)



484+242 Tone_PUN1_CH151 (6705MHz)




484+242 Tone_PUN1_CH215 (7025MHz)




802.11be-EHT160 - Ant 6

996+484 Tone_40-PUN4_CH47 (6185MHz)



996+484 Tone_40-PUN4_CH111 (6505MHz)



996+484 Tone_40-PUN4_CH143 (6665MHz)




996+484 Tone_40-PUN4_CH207 (6985MHz)




802.11be-EHT160 - Ant 6


996+484+242 Tone_20-PUN5_CH47 (6185MHz)



996+484+242 Tone_20-PUN5_CH111 (6505MHz)



996+484+242 Tone_20-PUN5_CH143 (6665MHz)



996+484+242 Tone_20-PUN5_CH215 (7025MHz)



802.11be-EHT320 - Ant 6


2x996+484 Tone_PUN6_CH31 (6105MHz)



2x996+484 Tone_PUN6_CH95 (6425MHz)



2x996+484 Tone_PUN6_CH159 (6745MHz)




802.11be-EHT320 - Ant 6

3x996 Tone_80-PUN1_CH31 (6105MHz)



3x996 Tone_80-PUN1_CH95 (6425MHz)




3x996 Tone_80-PUN1_CH159 (6745MHz)




802.11be-EHT320 - Ant 6

3x996+484 Tone_40-PUN3_CH31 (6105MHz)



3x996+484 Tone_40-PUN3_CH95 (6425MHz)




3x996+484 Tone_40-PUN3_CH159 (6745MHz)




802.11a - Ant 7


Channel 2 (5935MHz)




Channel 1 (5955MHz)




Channel 49 (6195MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)




Channel 105 (6475MHz)




Channel 113 (6515MHz)




Channel 117 (6535MHz)




Channel 153 (6715MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)




Channel 213 (701MHz)



Channel 229 (7095MHz)




Channel 233 (7115MHz)




802.11be-EHT20 - Ant 7


Channel 2 (5935MHz)




Channel 1 (5955MHz)




Channel 49 (6195MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)




Channel 105 (6475MHz)




Channel 113 (6515MHz)




Channel 117 (6535MHz)




Channel 153 (6715MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)




Channel 213 (701MHz)



Channel 229 (7095MHz)




Channel 233 (7115MHz)




802.11be-EHT40 - Ant 7


Channel 3 (5965MHz)




Channel 51 (6205MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)




Channel 115 (6525MHz)




Channel 123 (6565MHz)




Channel 147 (6685MHz)




Channel 179 (6845MHz)




Channel 187 (6885MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)




802.11be-EHT80 - Ant 7


Channel 7 (5985MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)




Channel 135 (6625MHz)




Channel 151 (6705MHz)




Channel 167 (6785MHz)




Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




802.11be-EHT160 - Ant 7


Channel 15 (6025MHz)



Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11be-EHT320 - Ant 7

Channel 31 (6105MHz)



Channel 95 (6425MHz)



Channel 159 (6745MHz)



802.11be-EHT20 - Ant 7

26 Tone_RU0_CH1 (5955MHz)



26 Tone_RU8_CH93 (6415MHz)



26 Tone_RU0_CH97 (6435MHz)



26 Tone_RU8_CH113 (6515MHz)




26 Tone_RU0_CH117 (6535MHz)




26 Tone_RU8_CH181 (6855MHz)



26 Tone_RU0_CH189 (6895MHz)




26 Tone_RU8_CH233 (7115MHz)



802.11be-EHT20 - Ant 7

52 Tone_RU74_CH1 (5955MHz)



52 Tone_RU77_CH93 (6415MHz)




52 Tone_RU74_CH97 (6435MHz)



52 Tone_RU77_CH113 (6515MHz)



52 Tone_RU74_CH117 (6535MHz)




52 Tone_RU77_CH181 (6855MHz)



52 Tone_RU74_CH189 (6895MHz)




52 Tone_RU77_CH233 (7115MHz)




802.11be-EHT20 - Ant 7


106 Tone_RU106_CH1 (5955MHz)




106 Tone_RU107_CH93 (6415MHz)



106 Tone_RU106_CH97 (6435MHz)




106 Tone_RU107_CH113 (6515MHz)




106 Tone_RU106_CH117 (6535MHz)



106 Tone_RU107_CH181 (6855MHz)



106 Tone_RU106_CH189 (6895MHz)



106 Tone_RU107_CH233 (7115MHz)

