



802.11ax-HE40 – PSD – SISO Mode Ant 1 – 26 Tone RU 0


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



802.11ax-HE40 – PSD – SISO Mode Ant 1 – 26 Tone RU 8

Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 1 – 26 Tone RU 17


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 1 – 484 Tone RU 65


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE20 – PSD – SISO Mode Ant 2 – 26 Tone RU 0


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE20 – PSD – SISO Mode Ant 2 – 26 Tone RU 4


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)




802.11ax-HE20 – PSD – SISO Mode Ant 2 – 26 Tone RU 8

Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE20 – PSD – SISO Mode Ant 2 – 242 Tone RU 61


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 2 – 26 Tone RU 0


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 2 – 26 Tone RU 8


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 2 – 26 Tone RU 17


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE40 – PSD – SISO Mode Ant 2 – 484 Tone RU 65


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE20 – PSD –MIMO Mode - Ant 1 – 26 Tone RU 0


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)



802.11ax-HE20 – PSD –MIMO Mode - Ant 1– 26 Tone RU 4

Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)



802.11ax-HE20 – PSD –MIMO Mode - Ant 1 – 26 Tone RU 8


Channel 01 (2412MHz)



Channel 06 (2437MHz)




Channel 11 (2462MHz)




802.11ax-HE20 – PSD –MIMO Mode - Ant 1 – 242 Tone RU 61


Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)




802.11ax-HE40 – PSD –MIMO Mode - Ant 1 – 26 Tone RU 0


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE40 – PSD –MIMO Mode - Ant 1 – 26 Tone RU 8


Channel 03 (2422MHz)



Channel 06 (2437MHz)




Channel 09 (2452MHz)




802.11ax-HE40 – PSD –MIMO Mode - Ant 1 – 26 Tone RU 17


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)



802.11ax-HE40 – PSD – MIMO Mode - Ant 1 - 484 Tone RU 65


Channel 03 (2422MHz)



Channel 06 (2437MHz)



Channel 09 (2452MHz)




802.11ax-HE20 – PSD –MIMO Mode - Ant 2 – 26 Tone RU 0

Channel 01 (2412MHz)



Channel 06 (2437MHz)



Channel 11 (2462MHz)

