


SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Side 1	
2	Side 2	
3	Side 3	
4	Side 4	
5	Side 5	
6	Side 6	
Note: We choose the maximum results of each test positions to provide the cube locations.		

Phantom Position : Flat	EUT side : Side2
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side3
Spacing to phantom : 0 mm	Accessory : N/A

