

Setting up your Chromebook Tab

Choose your language & keyboard

LanguageEnglish (United States)

KeyboardUS

Connect to network

To restore your data, you need an Internet connection.

AcerGuest

AcerWireless-Instant

AcerWireless

K880T50, Tech, 2.4GHz

K880T50, Tech, 5GHz

Back

Next

Connect to a network

On the Connect screen, select the language, keyboard type, and then connect to a network. Click **Accept and continue** to check and accept the terms of service.

Google

Sign in to your Chromebook

Enter your email

Forgot email?

More options


Next

Back

Sign in with your Google account

In the sign-in box, enter your Google Account user name and password and click **Sign in**. If you do not have a Google Account, click **Create a Google Account** to set up a new account.

Getting to know your desktop



1. Launcher

Select **Launcher** and type in the search bar to find apps, documents, the web and more. You can view available apps in the **All Apps** list below the search box.

2. Pin your favorite apps

You can pin your favorite apps to the shelf by two-finger tapping the app and selecting **Pin to shelf**. To remove an app, two-finger tap the app and select **Unpin**.

3. Access controls, settings, information and help

In status area, you can see the battery and time information and change the settings of network connection, keyboard input method and so on. Click «?» to bring up Chrome OS Help.

Getting more information and help

For more information about your Chromebook Tab, please refer to the Chromebook Tab User's Manual. The User's Manual contains important regulatory information for your health and safety. You can download it from the Acer support website by going to:

- <http://go.acer.com/?id=17883>

What you can do with Google apps?

Accomplish your everyday work

Create documents with Google Docs

Make spreadsheets with Google Sheets

Do presentations with Google Slides



Tip

Google productivity apps support working with popular Microsoft Office formats. You can download Microsoft Office online apps such as Word online, Excel online, and Powerpoint online from the Chrome Web Store to work with all your Windows PC docs.

Chat with people

You can have video chats or group video chats using Hangouts

Listen to music

Tune in to massive music resources on Google Play Music

Watch videos, TV or Movies

If you like to watch videos or movies, between YouTube and Google Play Movies your options are almost limitless




Acer Chromebook Tab 10

D651N

SETUP GUIDE

Using the tablet for the first time



1 Plug in before turning on for the first time.

2 Press the power button.
Then follow the onscreen instructions to complete setup.

Inserting the stylus



Removing the stylus

