

## Instruction Manual

### How To Operate:

1. Open the battery door at the back of the unit. Use BATTERY CONNECTOR to snap on the terminals of a standard 9 volt battery. Be certain that male and female terminals are correctly matched. Place the battery into its housing and replace the BATTERY DOOR.
2. Turn on the both units by sliding button switch at the standby mode. You can see a LED brightening and then will turn it off.
3. Now you need to push any one unit of a on/call button at about 5 seconds then the other one unit will be received a ranging voice sound. The received unit depress a off button once that both units can communications with each other.
4. To transmit, hold the unit about 2 inches from your mouth to talk at the microphone. your unit can receive while the other one unit is transmitting.
5. Restore to standby mode if you need, depressing a off button once again.
6. When you have finished your communication, slide the off/standby switch to “off” position.

### Trouble Checklist :

#### PROBLEM

Walkie Talkie does not operate properly.

#### CHECK OR DO

Try a new set of batteries, your batteries may be defective or have low voltage.

Weak Transmission.

Hold walkie talkie so antenna is in vertical position.

Do not touch antenna with finger or hand. This will cause weak transmission. Check for obstructions between you and your friend.

\* We recommend using alkaline battery.

\* Do not use rechargeable battery.

\* Led indicator to show the need time of any modes:

a: Standby mode about four seconds to bright once again.

b: Hold a on/call button about one second to bright again.

c: Press a on/call button that the unit will be bright at all the time.

Please note: This unit is not recommended for use by children under three years of age.