


CM K 4

Model:9393 BACK 46-0468c (9393)

Gift Card for 9393



MADE IN CHINA



ALKALINE BATTERIES NOT INCLUDED.  
DO NOT MIX OLD AND NEW BATTERIES.  
DO NOT MIX ALKALINE, STANDARD,  
(CARBON ZINC), OR RECHARGEABLE  
(NICKEL-CADMIUM) BATTERIES.  
DO NOT USE RECHARGEABLE BATTERIES.  
PLEASE KEEP THIS PACKAGE FOR  
FUTURE REFERENCE.

#### Battery requirements

1 size "9V" or equivalent Alkaline Battery for each walkie talkie.  
(not included)

#### Note:

- Do not mix alkaline, Standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Different types of batteries or new and used batteries are not to be mixed.
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

#### Installation of batteries

Place the set face down on a flat surface. Press down on tabs to open battery cover.  
Insert 1 size "9V" or equivalent Alkaline Batteries as indicated inside the battery compartment. Close the battery cover. Push the tabs on the cover to snap into cabinet.

#### TO RECEIVE:

Turn the power on by sliding the power switch to "on" position.  
Your Walkie Talkie is now in receiving mode.

#### TO TRANSMIT:

With the power on, hold the talk button down and speak into the microphone. To receive a message, release the hold on the talk button.

#### MORSE CODE:

To practice: Set the unit to receiving mode. Press the morse code signal button to practice morse code from the chart.

#### SENDING MORSE CODE:

Set the unit to transmit mode. Press the morse code signal button as shown on the chart.

When the sound becomes weak, it is the time to replace the battery.

After use, slide the power switch to "off" position, in order to save the battery power.

The toy is not intended for children under 3 years old.  
Please retain this information for future reference.

**ADDITIONAL INFORMATION FOR WALKIE TALKIE 9393**

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

P/N: 45-0468A