




Annex A


Peak Excursion



10 Mhz High Channel




10 Mhz Low Channel






10 Mhz Mid Channel




20 Mhz High Channel






20 Mhz Low Channel




20 Mhz Mid Channel






5 Mhz High Channel



5 Mhz Low Channel





5 Mhz Mid Channel

