

HOST PRINTER MODEL: QL 220plus



EUT - Front View



EUT - Rear View



EUT - Right View



EUT - Left View

HOST PRINTER MODEL: QL 320plus



EUT - Front View



EUT - Rear View



EUT - Top View



EUT - Bottom View



EUT - Right View



EUT - Left View

HOST PRINTER MODEL: QL 420plus



EUT - Front View



EUT - Rear View



EUT - Top View



EUT - Bottom View



EUT - Right View



EUT - Left View