

CARE

The following suggestions will help you care for your Agitator so you can enjoy it for years.

- Do not drive the truck through puddles or mud, on a wet floor, or in sand, rain, or snow. These can damage it.
- Do not expose the truck or transmitter to temperature extremes, and do not store them in direct sunlight or near a heat source.
- Do not leave the truck or transmitter outside overnight. Night dampness can damage their electronic circuits.
- To protect the truck's mechanisms from lint and hair, do not drive the truck on carpet.
- Wipe the truck and transmitter with a damp cloth occasionally to keep them looking new. Do not use harsh chemicals to clean them.

Modifying or tampering with the truck's or transmitter's internal components can cause a malfunction and might invalidate the truck's warranty and void your FCC authorization to operate it. If your truck is not performing as it should, take it and the transmitter to your local RadioShack store for assistance.

THE FCC WANTS YOU TO KNOW

The Agitator or transmitter might cause TV or radio interference even when it is operating properly. To determine whether your truck or transmitter is causing the interference, turn both off. If the interference goes away, your truck or transmitter is causing the interference. Try to eliminate the interference by:


- Moving your truck and transmitter away from the TV or radio
- Contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using the Agitator and transmitter.

Note: The manufacture is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. such modifications cloud void the user's authority to operate the equipment.

USER-REPLACEABLE PARTS

You can order replacement parts for your vehicle at your local RadioShack store. Simply identify the part(s) you need from this exploded view, then find the part number in the list on Page 10.



Ref. No.	Description	RSU #	NP Part
1	Transmitter 27 MHz	12139119	ZA90181
2	Transmitter 49 MHz	12139127	ZA90182
3	Transmitter Antenna	11972601	A90056
4	Receiver Antenna Wire, 27 mhz 49mhz	12093324 12062113	A90120 A90106
5	Receiver Antenna Tube Set	10681781	HC4899
6	Receiver Battery Door	11972627	DB90210
7	Transmitter Battery Door	10611358	DB1064
8	Receiver Hardware Kit Consists of: Metal Screw 2.6 x 8PT (4) Metal Screw 3 x 12PM (4) Washer M3 (4) Washer 1010-9 (4)	12139093	HW6004236
9	Suspension Pillar Assembly (Front/back)	12139085	RA90354
10	Left Front Wheel Assembly	12139069	Z91853
11	Right Front Wheel Assembly	12139077	Z91854
12	Left Rear Wheel Assembly	12139044	Z91851
13	Right Rear Wheel Assembly	12139051	Z91852
14	Front Bumper Guard	11972684	Z90651
15	Rear Bumper Guard	11972692	Z90652
16	Truck Body Assembly with Label	12138970	Z91847
17 [†]	Service Manual	12139135	MS6004136
18 [†]	Owner's Manual	12139101	MU6004236

[†]Not shown in exploded view