

Instruction Manual for Model No. FRS-4622 Ear Band Talkie

Operation


- 1) Open the battery cover with a screwdriver , then insert 4 pcs “G13” button battery and close the battery compartment.
- 2) Slide the “on/off” switch to “on” position, then you can communicate with each other, only one person can talk at the same time.
- 3) Put the talkie fit on your ear, speak in a normal voice into the microphone. The microphone is voice-activated, so as soon as you begin talking your message will be transmitted to the other talkie. The microphone will be activated if wind blows directly into it. Adjust your position to avoid the wind and other outside noises that interfere with the microphone.
- 4) In the event of interference caused by other radio signals in the vicinity. Move to a different location.
- 5) The units may have feedback (squealing noise) when played too close together. Move farther apart when it happens.
- 6) Stop playing, slide to “off” position.

Care and Maintenance

- 1) Clean your unit with a damp (never wet) cloth, solvent or detergent should never be used.
- 2) Avoid leaving your unit in direct sunlight or in hot, humid or dusty places.
- 3) Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamps or motors.
- 4) When the sound of the unit becomes weak, it is the time to change batteries.

Warning

- 1) Do not try to use metal objects to short battery connector, it may damage your unit.
- 2) The manufacturer is not responsible for any unauthorized modifications to this equipment, such modifications could void the user's authority.
- 3) Specifications are subject to change without notice.



LOYAL TECHNOLOGY
FCC ID : ICK-FRS-4622
EXHIBIT # : 5

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY
TO OPERATE THE EQUIPMENT.