

Instruction Manual




WARNING:

CHOKING HAZARD – small parts
Not for children under 3 years.


Functions and Controls

1. Safe, Flexible Antenna
2. On / Off - WT Switch
3. Push-to-talk Button
4. Earphone
5. Earphone Jack
6. Microphone
7. LCD Display
8. Mode Button
9. Set Button
10. Watchband
11. Changeable Faces Cover
12. Battery Door Screw
(1 PC 'A' for Talkie, 5 PCs 'B' for Watch)
13. Battery Door



Battery Installation – Walkie Talkie

This Mini Watch Walkie Talkie is operated using with Eight standard Button Cell - DC 1.5 v (Vinnic #L1154 or equivalent #LR 44) size batteries (Four batteries for each unit).




(Make sure the four LR 44 batteries follow the polarity diagram)

1. Turn the On / Off - WT Switch (#2) to 'Off' position, Before replace the battery.
2. Open the battery door (#13) with '+' screwdriver. Follow the polarity diagram inside the battery compartment; connect four LR 44 batteries. Close the battery door.
3. If the unit is not to be used for an extended period of time, remove the batteries.
Old and leaking batteries can cause damage to the unit and may void the warranty.

Battery Installation – Watch

This Mini Watch is operated using with Two standard Button Cell - DC 1.5 v (Vinnic #S 736 S or equivalent # LR 41) size batteries (one battery for each watch).



(Make sure the four LR 44 & LR41 batteries follow the polarity diagram)

1. Turn the On / Off - WT Switch (#2) to 'Off' position, Before replace the batteries.
2. Open the battery door (#13) & BTM cover screws (5 pcs) with '+' screwdriver.
3. Follow the polarity diagram inside the battery compartment; connect one LR 41 battery. Close the BTM cover screws & battery door.
4. If the unit is not to be used for an extended period of time, remove the batteries.
Old and leaking batteries can cause damage to the unit and may void the warranty.

Operation of Walkie Talkie

1. Plug on the Earphone into the Earphone Jack, then put on the Earphone.
2. Switch the unit 'On' by sliding the On / Off - WT Switch (#2) and move to the 'On' position to activate your unit.
3. This Mini Watch Walkie Talkie is equipped with a hidden Microphone inside the watch.
4. To transmit a message, Push Push-to-talk Switch (#3) & talk clearly to the Microphone (#5) towards your mouth about 6 – 7cm far.
5. To receive a message, release the Push-to-talk Switch (#3).
6. To switch off the unit, slide On / Off - WT Switch (#2) and move to the 'Off' position.

Watch Feature

1. 12 Hour format
2. 31 Days monthly calendar
3. Display shows Hours, Minutes, Seconds and Day
4. 1 Second resolution count up, Working Range from 0 ~ 59 Seconds
(The Watch Feature may vary from Chip version.)

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.