



Quanta Today



ON6



## Step 1: Take apart KB & screw out the screws under the KB

Quanta Today




Push 3 kb locks, take off kb



Open membrane connector & take out kb






Screw out 10-M2X3L screws





## Step 2: Take apart Base


Quanta Today





### Step 3: Take apart battery




Quanta Today





## Step 4: Take apart Phone cable


Quanta Today






## Step 5: Pull out the plugs & take apart speaker

Quanta Today



Pull out all the plugs



Screw out 4-M2x4L screws fixed the speaker






## Step 6: Take apart main board

Quanta Today




Screw out 2-M2x3L screws  
fixed the main board






## Step 7: Take apart cradle cover


Quanta Today



Screw out 6 screws



Remove cradle cover




Quanta Confidential



## Step 8: Separate the display parts from top cover


Quanta Today





## Step 9: Take apart Bezel

Quanta Today



Screw out 4-M2x4L screws


Take apart Bezel





## Step 10: Separate LCD panel from LCD cover


Quanta Today







## Step 11: Separate L/R hinge from LCD panel

Quanta Today



Screw out 4-M2x2.5L screws



Left hinge screw



right hinge screw



All the parts have been separated