



Quanta Today




ON6



Step 1: Take apart KB & screw out the screws under the KB

Quanta Today




Push 3 kb locks, take off kb



Open membrane connector & take out kb







Screw out 10-M2X3L screws





Step 2: Take apart Base


Quanta Today





Step 3: Take apart battery




Quanta Today





Step 4: Take apart Phone cable



Quanta Today






Step 5: Pull out the plugs & take apart speaker

Quanta Today



Pull out all the plugs



Screw out 4-M2x4L screws fixed the speaker






Step 6: Take apart main board

Quanta Today




Screw out 2-M2x3L screws
fixed the main board






Step 7: Take apart cradle cover


Quanta Today



Screw out 6 screws



Remove cradle cover




Quanta Confidential

EXHIBIT 9A



Step 8: Separate the display parts from top cover


Quanta Today





Step 9: Take apart Bezel

Quanta Today



Screw out 4-M2x4L screws


Take apart Bezel





Step 10: Separate LCD panel from LCD cover


Quanta Today







Step 11: Separate L/R hinge from LCD panel

Quanta Today



Screw out 4-M2x2.5L screws



Left hinge screw



right hinge screw



Quanta Today



All the parts have been separated