## **Meet Your**






## Put in the card(s) & power on

- 1 Insert the SIM tool into the hole next to the SIM & microSD card tray to pop out the tray.
- Make sure you use the correct size SIM card and
- 2 Insert the SIM card(s) with the gold contacts down, then gently push the tray into the slot.

Add a microSD card (optional, sold separately) for additional storage.



an eSIM (embedded SIM card) in addition to the physical SIM card.
Contact your service provider for details if you want to activate and use it.

3 Press and hold the Power button (1) to turn on your phone, then follow the prompts to get started.

To turn off your phone, press the Power and Volume Up buttons ⊕+ ← at the same time.

## Help & more

Get answers, updates, and info:

- Help is here: From the home screen, swipe up and tap Settings > Help to learn how to use your phone and get support.
- Get more: Get software, user guides, and more at
- www.motorola.com/mymotog.
   Connect with 5G: 5G service plan and 5G network coverage required; available only in select areas; device not compatible with all 5G networks. Contact your service provider for details.
- Energy Label: The Energy Label and product information defined within Regulation (EU) 2023/1669 is available at https://eprel.ec.eu/opa.eu/screen/home:

Legal information. This guide provides important legal, safety, and regulatory information that you should read before using your product. For the complete legal information, from the home screen swipe up and tap

Settings > Q, then type Legal information, or visit

www.motorola.com/device-legal.

Dust and water resistance. For detailed information about your phone's dust and water resistance design and care tips. Swipe up and tap Settlings Help. or refer to the User Guide.

Charging and battery safety. The battery in your phone can be removed on the property of the property of

service manuals. To prevent possible burning and injury, always follow the instructions provided. To prevent possible burning and injury, the battery in your phone should only be removed by a Motorola-approved service center or similar skilled personnel. If your phone becomes unresponsive, press and hold the Power button until the screen goes dark and your phone restarts. The phone supports QC and USB PD fast charging. The power delivered by the charger must be between min 5 Watts required by the radio equipment, and max 30 Watts in order to achieve the 5 - 30 maximum charging speed. For the fastest charging speed, choose SW USB PD a Motorola 5W or higher USB-A QC (Quick Charge) charger and compatible QC cable (both may be sold separately), or a Motorola 33W or higher USB-C PD (Power Delivery) charger and compatible PD cable (both may be sold separately). Use of other chargers is not recommended

(both may be sold separately). Use of other chargers is not recomment and may impair the charging performance. Chargers that do not comply with applicable national standards may be unsafe, with risk of death or injury, and may cause slow charging or product damage. Don't charge your phone in temperatures below -20°C (-4°F) or above 45°C (13°F). To view applicable standards and to learn more, see the "Leval information" section of this quide, or visit

www.motorola.com/device-legal.

Operational warnings. Obey all local restrictions when using mobile devices in public areas, such as hospitals, airplanes, or schools.

 Potentially explosive areas: Potentially explosive areas are often, but not always, posted and can include blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

Turn off your phone before entering such an area, and do not charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Symbol key: Your charger, phone, battery (if user-removable), phone display, user's guide, or packaging may contain symbols, defined as follows:





For indoor use only



Don't dispose of your battery or phone in a fire.



The package and paper products that came with your phone should be recycled.

Warning about high volume usage. To prevent possible hearing damage, do not listen at high volume levels for long periods. When your headset volume reaches the high volume they bold, a warning shows. Tap OK to dismiss it, or wait one to five seconds, then press the Volume up button to dismiss the alert and enable the volume to continue to be adjusted.

Disposal & recycling. Don't dispose of your battery or mobile device with your household waste. For help recycling products and packaging responsibly, with www.motorola.com/recycling.

Extreme heat or cold. Don't use your phone in temperatures below -20°C (43°F) or above 45°C (13°F). Don't store or transport your phone in temperatures below -20°C (44°F) or above 60°C (140°F).

Legal disclaimers. Features, services and applications are network dependent and may not be available in all areas, additional terms/charges may apply. Product specifications and other information contained in this guide are believed to be accurate at the time of printing or release. Motorola reserves the right to correct or change any information without notice.

Arbitration. Your purchase is governed by a binding arbitration clause. For

your phone.

SAR information (on e-label). To view specific absorption rate (SAR) values for this phone, from the home screen swipe up and tap Settings > Q., then type Regulatory labels, from your phone's dialpad, type \*#07#, or visit www.motorola.com/sar.

more information and how to opt-out, see the legal guide that came with

THATESTRICTED :: MOTOROLA CONFIDE



