



EM30 PIANOSA

EM30 MAIN BOARD BOTTOM





EM30 MAIN BOARD TOP



EM30 Daughter BOARD Bottom

EM30 Daughter Board Top




**J1
Speaker Contact**

**Vibrator
Contact Points**


**MK1
Microphone**

**J11
RF Connector**

Daughter Board Bottom Layout



Main Board Bottom Layout





Internal back w/ shielding case



Internal back w/o shielding case



Keypad front



Keypad back



Internal back



Internal front