

Domino Q
Final DRAFT
Getting Started
Guide
Final DRAFT
21/03/2011

Dummy Page - To be discarded before printing

Use this template with A7MotoPortraitProduct1
StructApps. See the Reference Pages for template
user instructions.

Congratulations

MOTOROLA XT316

Your MOTOROLA **XT316** phone is loaded with features, including videos, music, Web access, a powerful set of business tools, and more—all in a stylish phone design.

- **Mobile video:** Record and watch videos, download or stream videos to watch on your phone.
- **Photos:** Take and share great photos with a high performance camera.
- **Web:** Get more from the Web, with support for Adobe® Flash® Player. Search, browse, everything you want to do, all made easier.

Note: Certain apps and features may not be available in all countries.

Caution: Before assembling, charging, or using your phone for the first time, please read the important legal and safety information packaged with your product.

More

- **Support:** Phone updates, PC software, online help and more at www.motorola.com/support.
- **Accessories:** Find accessories for your phone at www.motorola.com/products.

DRAFT - MOTOROLA CONFIDENTIAL
& PROPRIETARY INFORMATION

Your phone

the important keys & connectors



Note: Your phone might look a little different.

Contents

Let's go	5
Touchscreen & keys	8
Home screen	14
Calls	18
Contacts	25
Messaging	27
Text entry	30
Tips & tricks	32
Web	35
Photos & videos	37
Music	42
Personalize	47
Bluetooth™ wireless	49
Wi-Fi™	52
Security	54
Troubleshooting	55
Safety, Regulatory & Legal	56

Let's go

let's get you up and running

Assemble & charge

1 Cover off



2 SIM in



3 microSD in (may already be inserted)



4 Battery in



5 Cover on



6 Charge up



Caution: Please read “Battery Use & Safety” on page 56.

Tip: To save battery life, see “Battery tips” on page 33.

Turn it on & off

To turn on your phone, press Power  (on the top left).

To turn off your phone, press and hold Power , then touch **Power off**.

Note: This phone supports data-intensive apps and services. It is strongly recommended that you purchase a data plan that meets your needs. Contact your service provider for details.

Unlock

To unlock your phone, touch the unlock icon  and drag it to the right.

Sounds off & on

To turn phone sounds off, touch the sound icon  and drag it to the left.

Wi-Fi™ connect

You can use a Wi-Fi™ connection for even faster Internet access. Touch Menu  > **Settings** > **Wireless & networks** > **Wi-Fi settings**. Touch

Wi-Fi to turn it on and search for nearby wireless networks. Touch a network to connect. There's more in "Wi-Fi™" on page 52.



DRAFT - MOTOROLA CONFIDENTIAL
& PROPRIETARY INFORMATION

Touchscreen & keys

Touchscreen on/off

a few essentials

Your touchscreen is on when you need it and off when you don't.


- To make your touchscreen sleep or wake up, just press Power .
- When you hold the phone to your ear during calls, your touchscreen sleeps to prevent accidental touches.
- To make your touchscreen sleep when you put it in your pocket, touch Menu  > **Settings** > **Display** and check **In-pocket detection**.
- To let the touchscreen adjust brightness automatically, touch Menu  > **Settings** > **Display** > **Brightness** and check **Automatic brightness**.

Touch tips

Here are some tips on how to navigate around your phone.


Touch

To choose an icon or option, *touch* it.



Touch & hold


To open special options, *touch and hold* an icon or other item. Try it: In the home screen, touch  **Contacts**, then touch and hold a contact to open options.



Drag

To scroll through a list or move slowly, *drag* across the touchscreen. Try it: In the home screen, touch  **Contacts**, then drag your **Contacts** list up or down.

Tip: When you drag or flick a list, a *scroll bar* appears on the right. Drag the scroll bar to move the list to a letter A - Z.



Flick

To scroll through a list or move quickly, *flick* across the touchscreen (drag quickly and release).

Tip: When you flick a long list, touch the screen to stop it from scrolling.

Pinch-to-zoom

Get a closer look at maps, web pages, or photos. To zoom in, *touch* the screen with two fingers and then slide them apart. To zoom out, *drag* your fingers together.