

Mini WALKIE TALKIE Racing CAR

YS-2280B

YS-2279B

YS-2281B

5

yrs. old
and up



WARNING:

CHOKING HAZARD-

Small parts. Not suitable
for children under 3 yrs. old



PRECAUTIONS:

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries are to be removed from the toy before being charged [removable]
- Rechargeable batteries are only to be charged under adult supervision [removable]
- Different types of batteries or new and used batteries are not to be mixed
- Only batteries of the same or equivalent type as recommended are to be used
- Batteries are to be inserted with the correct polarity
- Exhausted batteries are to be removed from the toy
- The supply terminals are not to be short-circuited

BATTERY COMPARTMENTREQUIRES 2 X 23A
12V BATTERY

PACKAGING HAS TO BE
KEPT SINCE IT CONTAINS
IMPORTANT INFORMATION
SPECIFICATIONS AND
COLORS OF CONTENT MAY
VARY FROM ILLUSTRATION
ON PACKAGING

MADE IN CHINA

HOW TO OPERATE:

1. Operate the remote control to switch YS-2279B into radio battery consumption. The playback volume will be 50%.
2. Turn the YS-2279B switch to ON.
3. Press the talk button to start talking and speak to anyone who has the device.
4. Listen for YS-2279B's playback and listen from the speaker.
5. Turn the Antenna holder to hold the antenna when not in use.
6. The antenna should be held in an upright position for best transmission strength.
7. Turn Power ON/OFF to switch on/off the device.

SPEAKER / MIC

ANTENNA

ANTENNA HOLDER**TALK BUTTON****POWER
ON / OFF**

0-3

FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.