


G580 FITS

Setup Guide



logitech 

1. Complete molding setup in-app


Ensure completion of setup and eartip molding through the mobile app. Lightspeed audio will not work until mobile setup is completed.

App Name




2. Connect via LIGHTSPEED

Insert your wireless receiver dongle into a compatible device. Triple tap either the left or right earbud to connect to LIGHTSPEED.




Router interference

Ensure receiver is at least 2 m away from wifi router.



Pair to your mobile/BT device


Place earbuds into the case, closing, then opening the lid. Press and hold case button for 3 seconds. Select G580 FITS on your device.



Customize G580 FITS

Customize EQ, controls, and other settings through the MOBILE APP NAME while connected via *Bluetooth*[®].


Follow the link to download G HUB on your PC to control customize G580 FITS via LIGHTSPEED.



logitech.com/ghub

Switch between *Bluetooth*[®] and LIGHTSPEED


Triple tap the left or right earbud to switch between *Bluetooth*[®] and LIGHTSPEED.



- Double Tap (*Bluetooth*[®]) = Play/Pause
- Double Tap (LIGHTSPEED) = Mute/Unmute Mic
- Triple Tap = *Bluetooth*[®] to LIGHTSPEED
- Double Tap (while receiving phone call on bluetooth or LIGHTSPEED) = Answer/Hang up

Charging

Place the earbuds inside the case to charge.
Connect your case to the USB-C cable to recharge the case.



© 2022 Logitech. Logitech, Logitech G, Logi and their respective logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-011659 00A