




<Photographs of EUT>





<Antenna Location>



The separation distance for antenna to edge:

Antenna	To Top Side (mm)	To Bottom Side (mm)	To Left Side (mm)	To Right Side (mm)
WWAN Antenna-0	153	0.8	20	2
WWAN Antenna-1	147	0.8	1.2	59
WLAN/BT Antenna-6	0.8	152	11	36
WLAN Antenna-8	8	137	9	50

TX/RX Function	Support Band
TX/RX ANT0	GSM 850 WCDMA B5 LTE B12/41/42
TX/RX ANT1	GSM 1900




	WCDMA B2/4
RX ANT2	GSM 850 GSM 1900 WCDMA B2/B4/B5 LTE B12/41
RX ANT3	LTE B42
RX ANT4	LTE B41
RX ANT5	LTE B41
TX ANT6	BT/2.4G WLAN
RX ANT6	LTE B42 GNSS/BT/2.4G WLAN
RX ANT7	LTE B42
TX/RX ANT8	5G WLAN


**<Photographs of SAR Setup>**




Right Cheek  
(Head Mode)




Right Tilted  
(Head Mode)




Left Cheek  
(Head Mode)



Left Tilted  
(Head Mode)




Front Face of EUT with 1 cm Gap  
(Body-Worn Mode)




Rear Face of EUT with 1 cm Gap  
(Body-Worn Mode)




Left Side of EUT with 1 cm Gap  
(Body-Worn Mode)



Right Side of EUT with 1 cm Gap  
(Body-Worn Mode)




Top Side of EUT with 1 cm Gap  
(Body-Worn Mode)



Bottom Side of EUT with 1 cm Gap  
(Body-Worn Mode)




Front Face of EUT with 0 cm Gap  
(Limbs Mode)




Rear Face of EUT with 0 cm Gap  
(Limbs Mode)



Left Side of EUT with 0 cm Gap  
(Limbs Mode)



Right Side of EUT with 0 cm Gap  
(Limbs Mode)



Top Side of EUT with 0 cm Gap  
(Limbs Mode)