







EUT RFID Reader Remove Top View




EUT Remove from Connector View



Connection Board Top View



Connection Board Top View



Main Board Top View



Main Board Bottom View