

PHOTO. 3. EUT (Model RM-802 Transmitter) INSIDE VIEW




PHOTO. 4. EUT (Model RM-802 Transmitter) COMPONENT SIDE VIEW




PHOTO. 5. EUT (Model RM-802 Transmitter) SOLDERING SIDE VIEW




PHOTO. 6. EUT (Model RM-802 Receiver) COMPONENT SIDE VIEW



PHOTO. 7. EUT (Model RM-802 Receiver) SOLDERING SIDE VIEW




PHOTO. 8. EUT (Model RM-802 Receiver) SOLDERING SIDE VIEW

