

# Quick Installation Guide

BTW6.0 for Microsoft Windows® Vista

## Bluetooth USB Adapter

### Introduction

---

#### § PC System Requirements

- one available USB port
- Windows® Vista

#### § UHE Button Operation

Your Bluetooth USB adapter may have UHE button, this is applied in the condition when computer system is without BTW driver installed but need to make connection with Bluetooth enabled keyboard or mouse or any HID devices (Broadcom™ chip designed-in is preferred).

To enable the connection, please make sure first that the Bluetooth mode is disabled at the system's device manager, then press the UHE button from USB adapter to enable UHE mode to be ready for Bluetooth connection.

\*Tip : keep keyboard or mouse in pairing mode before pressing UHE button would make the connection be quicker and more smooth.


## Bluetooth Setup

Step 1. Put the CD-Rom into the computer's CD drive and click the button of software installation for **Windows Vista** from the menu screen.

The [Bluetooth device not found] window may appear, now, plug the USB Bluetooth adapter into the USB port,



Step 2. The software InstallShield wizard window appears and start setup automatically.




## Bluetooth Setup

Step 3. On the welcome screen, click [Next] to continue.



Step 4. Click [Next] to accept the default destination folder, click [Change] to browse to a new destination folder for the Bluetooth software.



## Bluetooth Setup

Step 5. Click [Install] to start program installation.




Step 6. Installation process is running.




## Bluetooth Setup

Step 7. Click [Finish] to complete the Bluetooth software installation.



Step 8. The system restart request will appear to ensure the configuration change, click [Yes] to restart now or [No] to restart the computer later.



After restarting the PC, please ensure the **Bluetooth Icon** resides in system tray.

## Bluetooth Device Setup

Make sure the Bluetooth USB adapter is available on your computer and the system is ready to add the Bluetooth device to pair it. Please follow below instructions to complete the Bluetooth pairing :

Step 1. Click the left button of Bluetooth Icon from your system tray to choose [Add a Bluetooth Device] to the Add Bluetooth Device Wizard.




## Bluetooth Device Setup

Step 2. Click [Next].




Step 3. Select the Bluetooth device that you want to add, then click [Next]



## Bluetooth Device Setup

Step 4. You need to enter the Passkey. You can select whether you want Windows to generate a Passkey for you, or use a specific Passkey contained in the documentation of the Bluetooth device, or choose a passkey yourself.



Step 5. Complete the Bluetooth device installation.



## Bluetooth Device Setup

Step 6. The Bluetooth device now is added, you can select it and click [OK] to make connection.



Caution : changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

***Federal Communication Commission Interference Statement***

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***FCC Caution*** :To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

***FCC Radiation Exposure Statement***

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This device complies with Part 15 of the FCC Rules and RSS-210 of Canada.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.



CE 0681 FC