



國際電器認證中心有限公司 International Electrical Certification Centre Ltd.

提供電器產品測試國際認證及諮詢服務 Technical Services in Electrical Product Testing, International Certification & Information

FCC ID: KVR12148


Agent of 
Accredited Laboratory

Exhibit 5 - User's Manual

Head Office

Unit 602-605, 6/F, 31 Lok Yip Road, On Lok Tsuen, Fanling, NT, Hong Kong Tel (852) 2305 2570 Fax (852) 2756 4480

香港新界粉嶺安樂村樂業路31號6樓602-605室 電話 (852) 2305 2570 傳真 (852) 2756 4480



RADIO CONTROL CORVETTE® OPERATING INSTRUCTIONS




FIGURE 1: AA SIZE (Diagram 1)

BATTERY LOADING
(FOR MAXIMUM PERFORMANCE,
USE ALKALINE BATTERIES)
REMEMBER TO TAKE OUT ALL
BATTERIES
FROM CAR AND TRANSMITTER AFTER
PLAYING.

VEHICLE

1. Open battery compartment door at bottom of vehicle and insert 6 "AA" size batteries as indicated. (See the diagram below.)
2. Close battery door.

TRANSMITTER

1. On back transmitter unit, open battery compartment door and insert four "AA" size batteries.
2. Replace battery cover.




FIGURE 2: AA SIZE (Diagram 2)

- BATTERY CAUTIONS:**
1. Never use rechargeable batteries and do not mix rechargeable and non-rechargeable batteries.
 2. Do not use batteries that are old, damaged, or have been used in other toys.
 3. Do not use batteries that are not the correct type or size.
 4. Do not use batteries that are not the correct polarity.
 5. Do not use batteries that are not the correct voltage.
 6. Do not use batteries that are not the correct brand.
 7. Do not use batteries that are not the correct model.
 8. Do not use batteries that are not the correct type.

WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 years.



• FORWARD • STOP • REVERSE


- A. Slide the ON/OFF switch at bottom of car to the "ON" position.
- B. Place the car onto the floor. The car should stand still. If it does not, there may be on outside interference in the area. Move to another location.
- C. Press the button of controller, car will move forward. Release button car will stop. (Refer to diagram 1)
- D. Press the button of controller a second time, car will reverse in a circular path. Release button and car will stop.
- E. After playing with car, slide the ON/OFF switch of car to the "OFF" position.

Special information :

This car has a safety feature to protect the circuits from overheating during abnormal use, you may need to switch off the car and wait for a few minutes. So the car will work properly again.

IMPORTANT:

Did you know?
Your new radio control vehicle is controlled by sensitive electronic mechanism which should give you many hours of excitement and fun if you follow the instructions closely. Failure to follow the instructions could result in serious malfunctions.



Caution :

- 1) Do not pick up the car while in motion.
- 2) Keep fingers, hair and loose clothing away from the wheels while the switch is at "ON" position. It is better to turn the switch to "OFF" position when you picking up the car on hand or put on the table.
- 3) Adult supervision is recommended if the car is played at the place with children under age of 3.

PROPER OPERATION AND STORAGE OF YOUR VEHICLE:

1. Best operation of vehicle is on a low pile carpet from you.
2. Always operate your vehicle within a range of 15 feet from you.
3. Always operate your vehicle on dry surfaces away from cars and other full-size vehicles.
4. Always store your vehicle in a cool, dry place.
5. Avoid water or damp locations which may damage the vehicle's electronics. If your vehicle ACCIDENTALLY gets wet and stops running, let it dry overnight before trying to run it again.
6. Avoid operating around CB radios, baby monitors, cordless phones, electrical appliances, electric baseboard heaters, high voltage electrical wires and large, steel-reinforced concrete buildings all of which may cause interference.

GUIDE FOR TROUBLESHOOTING:

Check the points below if you are experiencing difficulty. Sometimes an apparent malfunction is the result of a simple cause and effect as shown below.

SYMPTOM	PROBABLE CAUSE	CORRECTION
Vehicle runs slowly or will not run.	* Weak 9 volt controller battery.	* Check connector and vehicle's ON/OFF switch.
Erratic operation or only short range possible.	* Radio interference likely.	* Replace battery or check.
		* Replace with fresh alkaline batteries.
		* Change location (see point 6, PROPER OPERATION SECTION).

Corvette, Emblems are trademarks of General Motors Corporation © 1997. All rights reserved.
Trademark of The Goodyear Tire & Rubber Company Used with permission.

MADE IN CHINA

FAIRFIELD, N.J. 07004

MERITUS®
INDUSTRIES INC.

IF YOU HAVE ANY QUESTIONS, PLEASE CALL OUR CUSTOMER HOTLINE 1-800-807-2738