


Label ITC 2800 UHF

Design and parameters of the main label:



Design and parameters of the additional label for versions with the LTE module installed:



Label location at the back of the ITC 2800:

