


Device Label



This label will be placed on the center, back of the transmitter, located between the two back-plate screws.