



XMT-3 USER'S GUIDE

This transmitter is activated by pressing one of the four push button switches. Each button activates a different channel. When a button is pressed the red light will come on indicating that it is operating. If the red light does not come on or comes on very dimly, the battery may need to be replaced. To replace the battery:

1. Remove the two screws located on the back of the transmitter.
2. Remove the cover from the back.
3. Remove the old battery and replace with a new GP23A type battery.
4. Install the cover on the back.
5. Tighten the two screws on the back. Do not over-tighten them as the threads may strip out.

MODIFICATIONS

Changes or modifications to this unit could void the user's authority to operate the equipment.

This device complies with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.