



The Mask Data - Ant 0

802.11a


Channel 105 (6475MHz)




Channel 113 (6515MHz)




Channel 117 (6535MHz)




Channel 149 (6695MHz)



Channel 181 (6855MHz)




Channel 185 (6875MHz)




The Mask Data - Ant 0

802.11a


Channel 189 (6895MHz)



Channel 209 (6995MHz)




Channel 229 (7095MHz)




The Mask Data - Ant 0

802.11ax-HE20


Channel 1 (5955MHz)




Channel 49 (6195MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)



Channel 105 (6475MHz)




Channel 113 (6515MHz)




The Mask Data - Ant 0

802.11ax-HE20


Channel 117 (6535MHz)




Channel 149 (6695MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 209 (6995MHz)







The Mask Data - Ant 0

802.11ax-HE40


Channel 3 (5965MHz)




Channel 51 (6205MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)



Channel 107 (6485MHz)




Channel 115 (6525MHz)




The Mask Data - Ant 0

802.11ax-HE40


Channel 123 (6565MHz)




Channel 147 (6685MHz)




Channel 179 (6845MHz)




Channel 187 (6885MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)







The Mask Data - Ant 0

802.11ax-HE80


Channel 7 (5985MHz)




Channel 55 (6225MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)



Channel 119 (6545MHz)




Channel 135 (6625MHz)




The Mask Data - Ant 0

802.11ax-HE80


Channel 151 (6705MHz)




Channel 167 (6785MHz)




Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




The Mask Data - Ant 0

802.11ax-HE160


Channel 15 (6025MHz)




Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)



Channel 143 (6665MHz)




Channel 175 (6825MHz)



The Mask Data - Ant 0

802.11ax-HE160


Channel 207 (6985MHz)




The Mask Data - Ant 0

802.11be-EHT20


Channel 1 (5955MHz)




Channel 49 (6195MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)



Channel 105 (6475MHz)




Channel 113 (6515MHz)




The Mask Data - Ant 0

802.11be-EHT20


Channel 117 (6535MHz)




Channel 149 (6695MHz)




Channel 181 (6855MHz)




Channel 185 (6875MHz)



Channel 189 (6895MHz)



Channel 209 (6995MHz)



The Mask Data - Ant 0

802.11be-EHT20

Channel 229 (7095MHz)

