



Delphi Deutschland GmbH
Controls & Security Electronics
Albert-Einstein-Straße 5
D-51674 Wiehl-Bonig
Phone: +49 (0)2261 / 971-0
Fax: +49 (0)2261 / 72691

Operating instructions for VO1-125kHz Immobilizer

The electronic immobilizer protects the car against theft using an electronic engine locking device, thus the engine cannot be cranked.

To be able to start the engine an authentication of the presence of an authorised key will be performed via the immobilizer system. This operation will be initiated by pressing a start button inside of the car by the user. Only when an authorised key is present in the reading range of the immobilizer system the engine will be enabled to start by the engine management control unit.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,
including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY RADIO OR TV Interference caused by unauthorized modifications to this equipment.

Such modifications could void the users authority to operate the equipment.

IC Statement according to RSSGen:

Operation is subject to the following two conditions:

- 1) this device may not cause interference, and
- 2) this device may accept any interference, including interference that may cause undesired operation of the device.