

ELTA ELT new model ELiTe TRANSMITTER Photos

(from ELiTe User's Handbook):



Figure 20
ELT ELITE – Automatic Fixed – Detailed Description

Photos not contractual

1 – “ON” BUTTON

9 – INTERNAL DUAL FREQUENCIES
ANTENNA (Backup)

2 – BATTERY PACK COMPARTMENT

3 – LCD DISPLAY

4 – 3 COLOUR LED INDICATOR

5 – “ARMED” BUTTON

6 – “ARROW” BUTTON

7 – “OK” BUTTON

8 – “TEST or RESET” BUTTON

8 bis – FLASH WHITE LED

ELiTe in Automatic Fixed configuration (ELiTe TRANSMITTER installed on ELiTe AF-BRACKET) photos (from ELiTe User's Handbook):



Figure 2
ELiTe Automatic Fixed (AF) – Presentation

Photo Not Contractual

ELiTe in Survival configuration (ELiTe TRANSMITTER equipped with ELiTe Float) photos:

