

360.0 mm



## USER MANUAL

### Bluetooth® WIRELESS SPEAKER



WIRELESS



RECHARGEABLE

**FCC/Industry of Canada Information**

Precautions for the unit

- Do not use the unit immediately after transportation from a cold place to a warm place; condensation problems may result.
- Do not store the unit near fire, places with high temperature or in direct sunlight. Exposure to direct sunlight or extreme heat (such as inside a parked car) may cause damage or malfunction.
- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.

**Note:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Changes or modifications not expressly approved by Elytone Electronic Co., Ltd. could void the user's authority to operate the equipment.

**IMPORTANT SAFETY INSTRUCTIONS**

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

**CAUTION**

THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING THE USER TO THE DANGER OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT. THE EXPLANATION PROVIDED IN THE TRIANGLE IS A WARNING SIGN FOR THE USER TO READ THE FOLLOWING IMPORTANT INSTRUCTIONS FOR SAFETY IN USING THE PRODUCT. SEE MARKING ON BOTTOM / BACK OF PRODUCT

**WARNING:** TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use. Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions. Do not use this apparatus near water.

**ADDITIONAL SAFETY INFORMATION**

- Do not use unauthorized chargers or power adapters. Use only chargers that came with your product or that is listed in the user's guide.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- The marking information is located at the bottom of apparatus.

**IMPORTANT BATTERY INFORMATION**


Warning: Your product contains a battery and charging system which is designed to work in temperatures that do not exceed 50°C (122°F). Leaving this product in a closed automobile or the trunk of an automobile where temperatures may exceed 50°C may result in permanent battery damage, fire, or explosion. Please remove your product from the automobile when you exit, do not place your product in the trunk of your automobile, and do not leave your product in any location where temperatures may exceed 50°C.

**Ecology**

Your product must be disposed of properly according to local laws and regulations. Because this product contains a battery, the product must be disposed of separately from the household waste.

**General controls**


**Front Review**



**Rear Review**



**Bottom Review**



**(1) PAIR Button**

- Press and hold for 3 seconds to activate pairing mode

**(2) PAIR Indicator**

- Fast flash: ready for pairing
- Very slow flash: in Standby mode
- Slow flash: reconnecting to the most recently connected device
- Solid blue: Bluetooth connection established

**(3) LINE IN**

- 3.5 mm auxiliary input jack

**(4) DC IN**

**(5) Charging Indicator**

- Red: charging
- Off: battery full

**(6) ON/OFF Switch**

**Pairing**

- If the EBT-00201 is off, slide the ON/OFF switch to ON.
- The PAIR Indicator begins blinking. This indicates that the EBT-00201 is attempting to reconnect to a previously paired device.
- After a few seconds the PAIR Indicator begins blinking rapidly. This indicates that the EBT-00201 is now ready to pair.
- While the EBT-00201 is in pairing mode, select IFbyCLN from the list of Bluetooth devices of your phone.
- If your phone asks for a password/pin code, enter 0000 and press OK.
- Upon successful pairing, the EBT-00201 will beep once. It is now ready to use with your phone.

**Reconnecting**

When you turn it on, the EBT-00201 reconnects automatically with the last paired device. When you leave the Bluetooth operating range, with the EBT-00201 turned ON, it disconnects. When you come back into the Bluetooth operating range, press the PAIR button to reconnect the last paired device. The EBT-00201 will beep once it has been successfully reconnected.

**Standby**

If your device has not been connected for an extended period of time, it will enter standby to preserve battery life. In standby mode, the Pair LED indicator will blink slowly. From standby, quickly press the PAIR button to reconnect to the last connected device, or press and hold PAIR to initiate pairing. The PAIR Indicator will blink rapidly, and the speaker will be ready to receive a connection.

**Streaming music**

- Go to your phone's music player and play a track by pressing "Play". If the EBT-00201 is connected, the music will be heard directly in the speaker. See your phone manual if needed.
- For adjusting volume and controlling audio playback, please use the controls on your music player directly.

**Auxiliary source**

- Plug one end of the supplied audio cable into the LINE IN and the other end into the output of your music player.
- Press "Play" on your music player to stream music directly via the EBT-00201.
- For adjusting volume and controlling audio playback, please use the controls on your music player directly.

刀模線

折痕線

90.0 mm