

**Intertek Testing Services NA Inc.**

---

**EXHIBIT 7**

**INSTRUCTION MANUAL**

**7.0 Instruction Manual**

Attached is a preliminary copy of the Instruction Manual.

The information to the User shown on the attached page will be inserted into the packaging.

This manual will be provided to the end-user with each unit sold/leased in the United States.

## **Spiralux™**

### **Interference Instruction:**

*This product may cause interference with radios, cordless telephones and remote control devices . If interference occurs, relocate this product away from the device or plug into a different outlet.*

### **Application Instruction:**

*This lamp used with three way switch socket which can be used for incandescent three way lamp. The light output level is 20%, 75% and 100%. The light output will reach to the above level after a few minutes of switching.*

## **Spiralux™**

### **Interference Instruction:**

*This product may cause interference with radios, cordless telephones and remote control devices . If interference occurs, relocate this product away from the device or plug into a different outlet.*

### **Application Instruction:**

*This lamp used with three way switch socket which can be used for incandescent three way lamp. The light output level is 20%, 75% and 100%. The light output will reach to the above level after a few minutes of switching.*

## **Spiralux™**

### **Interference Instruction:**

*This product may cause interference with radios, cordless telephones and remote control devices . If interference occurs, relocate this product away from the device or plug into a different outlet.*

### **Application Instruction:**

*This lamp used with three way switch socket which can be used for incandescent three way lamp. The light output level is 20%, 75% and 100%. The light output will reach to the above level after a few minutes of switching.*