

BUTTON 1.



: A. Arm
B. Keep press 2" — Panic
C. When Ignition ON — Door Lock

BUTTON 2.



: A. Disarm
B. When Ignition on — Door Unlock

BUTTON 3.



: Remote start

BUTTON 4.



: Keep Press 2" — Trunk