

1. Button 1 : a. Arm; b. Keep press 3 second to Panic.
2. Button 2 : Disarm (and it will open the central lock on driver side.)
than press one more time in 5", it will open the central lock on other doors.
3. Button 3 : a. Remote 1st aux. output (Trunk pop).; b. Keep press 2-3" to remote 2nd aux. output.
4. Button 4 : Remote start --- press again to off.
5. Button 1+2: a. When arming --- keep press 3" to all (shock & option) sensor bypass.
b. When disarm --- press 3" to valet mode, when keep 6" to valet park mode.
6. Button 1+3: To anti-car jacking.
7. Button 2+4:Chirp defeat arm / disarm
8. Button 5: a. Show the company Logo or the last message.
b. Keep press 3" to Change Channel I or II (1st Car or 2nd Car).
c. Press 5 times to Voice or null voice prompt for button operation.