



## APPENDIX SETUP PHOTOS

### RADIATED MEASUREMENT SETUP

#### Normal operating Mode








## Charger Mode










### **RADIATED RF MEASUREMENT SETUP**







**ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP**



## **POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP**

### **Charger Mode**

