






























































LUXSHARE Main / Aux Antenna
Part No.: LA9RF204-CS-H
ASUS No.: 14008-03670000








Hong-Bo Main / Aux Antenna
Part No.: 260-26233
ASUS No.: 14008-03670100



Hong-Bo Main / Aux Antenna
Part No.: 260-26233
ASUS No.: 14008-03670100



Hong-Bo Main / Aux Antenna
Part No.: 260-26233
ASUS No.: 14008-03670100