

WARNING:
CHOKING HAZARD-Small parts.
Not for children under 3 years


TS-1280M/TS-1280F Love Beeper

INSTRUCTION MANUAL

Congratulations on your purchase of "LOVE BEEPER"- a beeper which can help you to find your dream lover!
Please read the following instructions to use it properly.

FEATURES

"ACTIVITY INDICATORS" - Shows you the activity you've selected.
(Dinner, Drink, Shopping, Movie, Get your love)




Love Beeper

HOW TO OPERATE

- 1) Press the "POWER" switch to turn on the unit. You will see all the lights blink for seconds.
- 2) Press the "MODE" key to set the activity you want. It will be shown on the blinking "Activity Indicator".
- 3) Carry "LOVE BEEPER" along and get ready for making your new friends!
- 4) The big "LOVE" lamp will flash and melody will play when another "LOVE BEEPER" (opposite sex) with the same activity selected get close to yours.
- 5) If the activities set on both "LOVE BEEPERS" are different, the smaller "ATTENTION" lamp will flash with beeping sound to alert you. If you like, you may try to match the other's activity by setting the "MODE" key. The "LOVE" lamp will flash if both activities are matched.

RATING: 3V ---2W
BATTERY: 2 X 1.5V (AAA) (DO NOT USE RECHARGEABLE BATTERIES)
 DO NOT MIX OLD AND NEW BATTERIES
 DO NOT MIX ALKALINE, STANDARD OR RECHARGEABLE BATTERIES.
 BATTERY INSTALLATION SHOULD BE DONE BY ADULT.
 NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.
 RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED (IF REMOVABLE).
 RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION (IF REMOVABLE).
 ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
 BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY.
 EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY.
 THE SUPPLY TERMINALS ARE NOT TO BE SHORT CIRCUITED.
 PLEASE KEEP THE INFORMATION FOR FUTURE REFERENCE.
 UNDER THE ENVIRONMENT WITH ELECTROSTATIC DISCHARGE, THE SAMPLE MAY MALFUNCTION AND REQUIRE USER TO RESET THE SAMPLE.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

*Love 6
Beeper*

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.