




Ying Leung International Ltd.

英良國際有限公司

Unit 3 & 4, 13/F., World-Wide Ind. Centre,
43-47 Shan Mei Street, Fo Tan, N.T., Hong Kong.
Tel: (852) 2609 3698 Fax: (852) 2609 3728

FRIEND.LINK

USER MANUAL



SLIDING SWITCH

In edit mode, slide the switch to scroll alphabet, digit or symbol

In other occasion, sliding switch serves as up/down pointer for files. (fast searching function)

UP KEY:-

In most cases, it serves as scrolling files/messages.

In edit mode, it scrolls alphabet, digit or symbol in ascending order.

DOWN KEY:-

In most cases, it serves as scrolling files/messages.

In edit mode, it scrolls alphabet, digit or symbol in descending order

LEFT KEY:-

To select icon.

In most cases, it serves as retrieving items and choice.

E.g. Hobbies:- (Computer/Games, Dinning, Movies,). Press left key to pick choices from left side.

In edit mode, it serves as cursor key (<-).

RIGHT KEY:-

To select icon.

In most cases, it serves as retrieving items and choice.

E.g. Hobbies:- (Computer/Games, Dinning, Movies,). Press left key to pick choices from right side.

In edit mode, it serves as cursor key (->).



Ying Leung International Ltd.

英良國際有限公司

Unit 3 & 4, 13/F., World-Wide Ind. Centre,
43-47 Shan Mei Street, Fo Tan, N.T., Hong Kong.
Tel: (852) 2609 3698 Fax: (852) 2609 3728

CANCEL KEY:-

To cancel a selection

CONFIRM/ENTER KEY:-

To confirm setting (exit setting mode) or to enter icon function or to enter setting mode or, enable/disable beep tone in real time mode

ON/OFF/SHIFT/ENABLE/DISABLE KEY-

Press and hold 3 seconds to turn off the whole unit. In edit mode, select digit, block letter or small letter. Turn on or off the RF transmission/reception in real time mode.

BATTERY :- 4.5V (3 X AAA SIZE BATTERY)

INITIALIZATION THE DEVICE:-

- Reset the game when changing batteries.
- Set real time clock
- Press and hold confirm key for 1.5s to enter setting mode.
- Refer key function for setting procedure.
- Set calendar.
- Set name (max. 16 character)
- Set password (max. 6 character)
- Select gender.
- Select age range.

ICONS AND FUNCTIONS:-

1)



PERSONAL DATA:-

Select hobbies.

- Use enter key to tick or cross choices.



Ying Leung International Ltd.

英良國際有限公司

Unit 3 & 4, 13/F., World-Wide Ind. Centre,
43-47 Shan Mei Street, Fo Tan, N.T., Hong Kong.
Tel: (852) 2609 3698 Fax: (852) 2609 3728

2)



FRIEND DATA:-

- Set friend's password. (max. 6 character)
- Max. Up to 6 friends' password.
- Select finder's gender.
- Select finder's age range.
- Select finder's hobbies.

3)



MESSAGES DELIVER:-

A) PB MODE:-

PB - stand for public broadcast.

1 message for max. 54 characters.

- Enter key to enable or disable message delivery in PB mode.
- *PB = enable message deliver. PB = disable message deliver.

Press left cursor in PB mode. And use enter key to select how to sent the message. (Everyone, Male, or Female)

B) FB MODE:-

FB - stand for friend broadcast.

6 message for max. 54 characters each. (FB1 --- FB6)

- Enter key to enable or disable message deliver in FB mode.
- *FB1 = enable FB1 message deliver. FB1 = disable FB1 message deliver.

4)



PUBLIC MESSAGE PICKUP:-

Use up, down, left, right cursor to view message.

Select the message, press and hold cancel key 1.5s to cancel the message.

- or, press and hold enter key 1.5s to lock the message.



Ying Leung International Ltd.

英良國際有限公司

Unit 3 & 4, 13/F., World-Wide Ind. Centre,
43-47 Shan Mei Street, Fo Tan, N.T., Hong Kong.
Tel: (852) 2609 3698 Fax: (852) 2609 3728

5)



FRIEND MESSAGE PICKUP:-

To view friend message.
Up to 12 messages memory capacity.

6)



FORTUNE TELLER GAME.

PRESS ENTER KEY TO SEE YOUR FORTUNE.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING:- Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:- This equipment has been tested and found to comply with the limits for class b digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures;



Ying Leung International Ltd.

英良國際有限公司

Unit 3 & 4, 13/F., World-Wide Ind. Centre,
43-47 Shan Mei Street, Fo Tan, N.T., Hong Kong.
Tel: (852) 2609 3698 Fax: (852) 2609 3728

- ☐ Reorient or relocate the receiving antenna,
- ☐ Increase the separation between the equipment and receiver,
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.