



- INTERNAL PHOTOS -

- 1ST MODULE




-2ND MODULE




BOTTOM




CONTROL BOARD




ERROR AMP



FIRST FLOOR_INNER




FIRST FLOOR_TOP




FRONT




INNER




LEFT




MAIN AMP



MAIN DRIVER AMP




PILOT MODULE



HCT CO., LTD.

105-1, Jangam-ri , Majang-Myeon, Icheon-si, Kyunggi-Do, 467-811, KOREA
TEL:+82 31 645 6300 FAX:+82 31 645 6401 www.hct.co.kr

POWER BOARD




REAR





RIGHT





TOP
































HCT CO., LTD.


105-1, Jangam-ri , Majang-Myeon, Icheon-si, Kyunggi-Do, 467-811, KOREA
TEL:+82 31 645 6300 FAX:+82 31 645 6401 www.hct.co.kr














HCT CO., LTD.

105-1, Jangam-ri , Majang-Myeon, Icheon-si, Kyunggi-Do, 467-811, KOREA
TEL:+82 31 645 6300 FAX:+82 31 645 6401 www.hct.co.kr

