

Annex B External Photographs of the EUT

Photo documentation of EUT for Trunk configuration

Photo 3: EUT for Trunk configuration



Photo 4: EUT for Trunk configuration



Photo 5: EUT for Trunk configuration



Photo 6: EUT for Trunk configuration



Annex C Internal Photographs of the EUT

Photo documentation of EUT for Trunk configuration

Photo 7: EUT for Trunk configuration



Photo 8: EUT for Trunk configuration



Photo 9: EUT for Trunk configuration



Photo 10: EUT for Trunk configuration



Annex D External Photographs of the EUT

Photo documentation of EUT without Trunk configuration

Photo 15: EUT without Trunk configuration



Photo 16: EUT without Trunk configuration



Annex E Internal Photographs of the EUT

Photo documentation of EUT without Trunk configuration

Photo 17: EUT without Trunk configuration



Photo 18: EUT without Trunk configuration



Photo 19: EUT without Trunk configuration



Photo 20: EUT without Trunk configuration

