



13.1.1. ATENNA LOCATIONS AND SEPARATION DISTANCES




14. TEST SETUP PHOTOS

1 HORIZONTAL-UP / 180° w/ 0.5 cm separation distance
(Inserted to Lenovo laptop, T60)



2 HORIZONTAL-DOWN / 180° w/ 0.5 cm separation distance (Worst-case)
(w/ short USB cable connected to Lenovo Laptop, T60)



3 VERTICAL-FRONT / 180° w/ 0.5 cm separation distance
(w/ short USB cable connected to Lenovo Laptop, T60)



4 VERTICAL-BACK / 180° w/ 0.5 cm separation distance
(Inserted to Lenovo laptop, T60)



5 TIP / 180°w/ 0.5 cm separation distance
(w/ short USB cable connected to Lenovo Laptop, T60)



15. EUT EXTERNAL PHOTO

USB – Horizontal Up



USB - Horizontal Down



END OF REPORT