


尺寸：77.5*57mm 骑马钉 页码按文件顺序 100G 单铜纸



封底

封面

Model Number: Trophy Buzzer 1.0

The Trophy Buzzer is a great friend for all of us who regularly walk away from our phone and/or spend too much time looking for our most valuable companion.

1. Compatibility:

- iPhone 4s
- iPhone 5
- iPad3
- iPod (new model launched October 2012)

2. How it works:

By pressing the Trophy Buzzer, your device will alert you with an alarm/sound so you can locate it with ease. The device works within 8 meters. (Depending on interference of other electronic devices, thickness of walls and

more, the distance may be lower than 8m at times.) Secondly, there is an Auto-Buzz Function – when you walk more than 8 meters away from your Smartphone, the alarm will sound. Thirdly, there is a great Reverse Buzz function. Attach the Trophy Buzzer to your key-chain, car-key or bag and find it by pressing the "PRESS"-key on the MAIN-menu in the APP.

3. Getting Started / Installation:

- (1) Download the App "Trophy Buzzer" in iTunes App store.
- (2) Open the app.
- (3) Make sure your Smartphone's Bluetooth is turned on in settings.
- (4) Tap the "Settings" (gear icon) in the app menu.
- (5) Remove the "plastic film" from the Smart Buzzer.
- (6) Switch on the "Trophy Buzzer" by holding the small button for 3 secs. (This is only needed the first time you use it. After this, the Trophy Buzzer will always be ON, only being in sleep mode while not in use.)

- (7) Under the "Bluetooth" label, press "search for device".
- (8) You should see your device, tap to pair the Trophy Buzzer with your device.

(9) After you finished pairing, test the function by pressing the Power-key on the Trophy Buzzer.

(10) In "App settings", chose ON/OFF on the three different functions, Trophy-Finder, Auto-Finder, Reverse-Finder.

(11) Also, Refer to the different functions below for explanation of the different functions.


4. Operation Manual

ⓘ Upper key : Power On/Off

ⓘ Lower key: Beep ringtone activate/deactivate

- Trophy Buzzer (Find your smartphone).
- Press and hold the Lower key on your Buzzer for 2 seconds.

- Phone will keep ringing until you press the button in the app.
- Reverse Buzzer (Find your buzzer).
- Press the button in the app.
- Your buzzer will keep ringing until you press the Lower key button on the device.
- Auto Buzzer (Automatic reminder).
- Your buzzer will sound automatically when it is more than 8 meters away from your smartphone.
- Will keep ringing until you press the Lower key button.




(1) Main page




(2) Connect with Device

- Turn on bluetooth on your phone.


- b. Press the "Search for Device" in the Trophy Buzzer App.
- c. Press the "Device" button (2nd Lower key).




(3) Ringtone selection



(4) Device alarm distance



(5) Help



5. Key Functions :

- 1) Link loss (alarm) for foreground (App on) and Background (APP off) modes

- and BLE connected.
- 2) Find Me (phone alarm to Device , Find Me , and device alarm to phone) for foreground (App on) and Background (APP off) modes and BLE connected.
- 3) Re-link : App-on will auto search device when device and phone disconnect within 20 seconds, if the device paired with 4S beforehand. When device and phone disconnect over 20 seconds, long press the device button to reconnect.
- 4) Buzzer (alert level , link loss level) : APP to set up buzzer into following mode , turn off , turn on.
- 5) APP could device's display battery status (%).
- 6) User could define customized distance to alarm buzzer under APP On mode (only).

6. Support

For Support issues, please refer to www.trophy.se.

7. Warranty
1 year.

FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



CE

ROHS

German

Modellnummer: Trophy Buzzer 1.0

Trophy Buzzer ist ein hervorragendes Hilfsmittel für alle, die regelmäßig ihr Smartphone vergessen oder verlieren und viel zu viel Zeit damit verbringen, den meist treuen Gefährten wiederzufinden.

1. Kompatibilität:

- iPhone 4s
- iPhone 5
- iPad3
- iPod (welches im Oktober 2012 veröffentlicht wurde)

2. So funktioniert es:

Sie suchen Ihr Smartphone oder Tablet? Drücken Sie einfach Ihren Trophy Buzzer. Diese App lässt in einem Radius von 8 Metern einen Klingelton erklingen, der es ermöglicht das Gerät schnell wiederzufinden (andere

elektronische Geräte oder massive Wände können die Reichweite der App beeinträchtigen). Trophy Buzzer hat zudem eine Auto-Buzz-Funktion, d.h. das Handy alarmiert Sie automatisch sobald Sie sich mehr als 8 Meter von diesem entfernen. So können Sie Ihr Smartphone oder Tablet niemals vergessen. Außerdem können Sie mithilfe der Trophy Buzzer-App Ihren Trophy Buzzer wiederfinden, den Sie zuvor am Schlüssel oder an Ihre Tasche angebracht haben.

3. Installation:

- (1) Laden Sie die App "Trophy Buzzer" vom iTunes App Store runter.
- (2) Starten Sie die App.
- (3) Achten Sie darauf, dass unter Einstellungen die Bluetooth-Einstellungen eingeschaltet sind.
- (4) Im Menü der Trophy Buzzer-App klicken Sie auf "Settings" (das Zahnradsymbol).

- (5) Entfernen Sie die Schutzfolie von Ihrem Trophy Buzzer.
- (6) Halten Sie den oberen Knopf für 3 Sekunden gedrückt, um den Trophy Buzzer zu aktivieren (das brauchen Sie nur bei der ersten Verwendung machen. Von nun an ist er immer angeschaltet oder im Stand-By-Modus).
- (7) In der App, wählen Sie "Bluetooth". Gehen Sie dann auf "search for device".
- (8) Ihr neuer Buzzer sollte jetzt als Alternative erscheinen. Klicken Sie diese an, um den Buzzer mit Ihrem Smartphone zu verknüpfen.
- (9) Wenn die Geräte verknüpft sind, drücken Sie den oberen Knopf vom Trophy Buzzer, um die Funktion zu testen.
- (10) Unter dem Punkt "App Settings" können Sie drei verschiedene Funktionen wählen: Trophy Buzzer, Auto Buzzer und Reverse Buzzer.
- (11) Unten finden Sie die Beschreibungen zu den unterschiedlichen Funktionen.


4. Gebrauchsanweisung

● Oberer Knopf: AN/AUS

● Unterer Knopf: Ton aktivieren/deaktivieren

- Trophy Buzzer (Smartphone oder Tablet finden).
- Den unteren Knopf für 2 Sekunden drücken.
- Das Gerät gibt einen Alarmton ab, bis er in der App abgeschaltet wird.
- Reverse Buzzer (Buzzer finden).
- Knopf in der App drücken.
- Ihr Buzzer gibt einen Alarmton ab, bis er mit dem unteren Knopf abgeschaltet wird.
- Auto Buzzer (Automatische Erinnerung).
- Ihr Buzzer gibt automatisch den Alarmton ab, wenn er länger als 8 Meter von dem Gerät entfernt ist.

- Der Alarmton wird mit dem unteren Knopf abgeschaltet.




(1) Hauptseite



(2) Verbinden Sie den Smart Buzzer mit Ihrem Smartphone


a. Bluetooth auf Ihrem Smartphone einschalten.

- b. In der Smart Buzzer-App die Wahl "Search for Device" drücken.
c. Wählen Sie den Buzzer wenn er auf dem Display angezeigt wird.



-20-

(3) Ton wählen



-21-