


**(4) Abstand für den automatischen Alarm wählen**



-22-

**(5) Hilfe**



For Support issues, please refer to www.trophy.se.  
5. Support

-23-

**6. Warranty**  
1 year.

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

**FCC Note:**  
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

-24-



Press Always Recycle



-25-

## Svenska

### **Modellnummer: Trophy Buzzer 1.0**

Trophy Buzzer är ett utmärkt hjälpmmedel för alla oss som regelbundet glömmar eller tappar bort telefonen och ägnar attledes för mycket tid till att efter var mest värdefulla följestagare.

#### **1. Kompatibilitet:**

- iPhone 4s
- iPhone 5
- iPad3
- iPod (nya modellen som släppes i oktober 2012)

#### **2. Så funkar det:**

Genom att trycka på din Trophy Buzzer kommer din telefon eller surfplatta att ge ifrån sig ett ljud så att du enkelt kan hitta den. Enheten fungerar inom en radie om 8 meter (eventuella störningar från andra elektroniska hjälpmmedel

väggars tjocklek och liknande kan i visa fall fortkonta kapaciteten något). Trophy Buzzer har också en Auto-Buzz-z-funktion - när du går mer än 8 meter ifrån din telefon så kommer alarmet att gå igenom så att du inte riskerar att glömma den. Sist men inte minst så finns också buzzerns omvända funktion som hjälper dig att hitta din Trophy Buzzer. Koppla buzzer till din nyckelknippa, bilnyckel eller väska och hitta den enkelt genom att trycka på en knapp i din Trophy Buzzer-app i telefonen.

#### **3. Kom igång/installation:**

- (1) Ladda ner appen "Trophy Buzzer" i iTunes App store.
- (2) Öppna appen.
- (3) Se till att Bluetooth-inställningarna är påslagna i inställningar på telefonen.
- (4) Klicka på "Settings" (kugghjulssymbolen) i appens meny.
- (5) Ta bort plastfilmen från din Trophy Buzzer.
- (6) Sätt på din Trophy Buzzer genom att hålla inne den övre knappen i 3

sekunder (detta behöver du bara göra första gången du använder din buzzer. I försättningen kommer den alltid att vara påslagen, fast i viloläge när den inte används).

(7) Gå in på "Bluetooth" i appen. Klicka på "Search for device".

(8) Din nya buzzer bör dyka upp som alternativ. Klicka på den för att parkoppla den med din telefon.

(9) När parkopplingen är genomförd, testa så att den fungerar genom att trycka på den Övre knappen på din Trophy Buzzer.

(10) I "App Settings" kan du välja att sätta på eller av de tre olika funktionerna:

Trophy Buzzer, Auto Buzzer och Reverse Buzzer.

(11) Se förklaringar av de olika funktionerna nedan.

#### 4. Bruksanvisning

##### ○ Övre knappen: Styrn AV/PA

##### ○ Nedre knappen: Adverte/natthvera ringignal

- Trophy Buzzer (Hitta din telefon).
- Tryck och håll inne den Nedre knappen på din Trophy Buzzer i 2 sekunder.
- Tryck och håll inne den Nedre knappen på knappen i appen.

- Telefonen kommer att tala tills du trycker på knappen i appen.

- Reverse Buzzer (Hitta din Buzzer).


- Tryck på knappen i din app.

- Din buzzer kommer att låta tills du trycker på den Nedre knappen på enheten.

- Auto Buzzer (Automatisk påminnelse).

- Din buzzer börjar automatiskt tala om den kommer längre än 8 meter ifrån din telefon.

- Ljudet fortsätter tills du trycker på den Nedre knappen på enheten.



-29-

(1) Hemtsida




(2) Koppla din Trophy Buzzer med din smartphone


- a. Sätt på bluetooth på din telefon.

- b. Klicka på "Search for Device" i din Trophy Buzzer-app.

c. Välj din buzzer när den dyker upp.




(3) Välj ringsignal




-32-

(4) Ställ in alarm-avstånd



-33-

## (5) Help



## 6. Warranty

1 year.

### FCC Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

## 6. Support

For Support issues, please refer to [www.trophy.se](http://www.trophy.se).

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



**for electronic waste** **WEEE**

Please Always Recycle

尺寸: 77.5\*57mm 骑马钉 页码按文件顺序 100G 单铜纸



## User Manual

Smart Buzzer1.0

封底

封面

**English**

**Model Number: Smart Buzzer 1.0**

The Smart Buzzer is a great friend for all of us who regularly walk away from our phone and/or spend too much time looking for our most valuable companion.

**1. Compatibility :**

- iPhone 4s
- iPhone 5
- iPad3
- iPod (new model launched October 2012)

**2. How it works :**

By pressing the Smart Buzzer, your device will alert you with an alarm/sound so you can locate it with ease. The device works within 8 meters. (Depending on interference of other electronic devices, thickness of walls and

more, the distance may be lower than 8m at times.) Secondly, there is an Auto-Buzz Function – when you walk more than 8 meters away from your Smartphone, the alarm will sound. Thirdly, there is a great Reverse Buzz function. Attach the Smart Buzzer to your key-chain, car-key or bag and find it by pressing the "PRESS"-key on the MAIN-menu in the APP.

### 3. Getting Started / Installation:

- (1) Download the App "Smart Buzzer" in iTunes App store.
- (2) Open the app.
- (3) Make sure your Smartphone's Bluetooth is turned on in settings.
- (4) Tap the "Settings" (gear icon) in the app menu.
- (5) Remove the plastic film\* from the Smart Buzzer.
- (6) Switch on the "Smart Buzzer" by holding the small button for 3 secs. (This is only needed the first time you use it. After this, the Smart Buzzer will always be ON, only being in Sleep mode while not in use.)

-2-

(7) Under the "Bluetooth" label, press "Search for device".

(8) You should see your device, tap to pair the Smart Buzzer with your device.

(9) After you finished pairing, test the function by pressing the Power-key on the Smart Buzzer.

(10) In "App settings", chose ON/OFF on the three different functions, Smart-

Finder, Auto-Finder, Reverse-Finder.

(11) Also, Refer to the different functions below for explanation of the different functions.

#### 4. Operation Manual

○ **Upper key : Power On/Off**

○ **Lower key: Beep/ringtone activate/ deactivate**

\*Smart Buzzer (Find your smartphone).

• Press and hold the Lower key on your Buzzer for 2 seconds.


• Phone will keep ringing until you press the button in the app.

-3-

- Reverse Buzzer (Find your buzzer).
- Press the button in the app.
- Your buzzer will keep ringing until you press the Lower key button on the device.

- Auto Buzzer (Automatic reminder).
- Your buzzer will sound automatically when it is more than 8 meters away from your smartphone.

- Will keep ringing until you press the lower key button.
- Will keep ringing until you press the lower key button.



-4-

**(1) Main page**



**(2) Connect with Device**

- a. Turn on bluetooth on your phone.

-5-