

## External Photos


### EUT Front View



### EUT Connect to PC via USB



EUT Back View



EUT Front View



EUT Back View

