

ATS 2

Operational Manual

Sovereign Tracking System LLC.


PalTrack

ATS 2 unit Installation and Operational Instructions

Asset Tracking System II(ATS 2)

The ATS 2 designed by Sovereign Tracking System LLC. provides a very affordable and accurate tracking system for locating and position asset and product within localized facilities. The attachment of the ATS 2 unit to an asset or product is performed in the following steps:

Adhesive side



Activation Pin

1. Open the packaging and remove the ATS 2 transmitter.
2. Attach the ATS 2 to an asset or product by orienting the transmitter assembly to the asset or product so that the adhesive side of the transmitter is facing towards object.
3. Remove the protective adhesive paper from the ATS 2 transmitter.
4. Orient the ATS 2 to the desired location on the asset or product, and press the ATS 2 FIRMLY to the asset or product.
5. DO NOT TRY TO RELOCATE OR REMOVE THE ATS 2 FROM THE ATTACHED ITEM.
6. IF THE ATS 2 IS REMOVED FROM THE Asset, it will be set to alarm mode.
7. Once the ATS 2 is secured to and asset or product, verify operation of the system by moving the ATS 2 transmitter either up or down, or side to side, and verify the data on the computer. For details on computer operation, reference PalTrack installation manual.

Notice: The changes or modifications not expressly by the party responsible for compliance could void the user's authority operate the equipment.

Model : 11401-1100

FCC ID.: N8TSOV230

THIS DEVICE COMPLES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO
CONDITIONS. (A) THIS DEVICE MAY NOT CAUSE
HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST
ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING
INTERFERENCE THAT MAY CAUSE UNDESIRE
OPERATION.

MADEIN TAIWAN