



- Keep LIGHT FLOWER away from dust and dirt, which can cause premature wear of parts.
- Wipe LIGHT FLOWER with a damp cloth occasionally to keep it looking new. Always unplug LIGHT FLOWER when cleaning the glass dome. You can use any good glass cleaner with a soft, clean cloth.

However, your equipment might cause radio or TV interference even if it is operating properly. If this equipment does cause radio or TV interference, which can be determined by unplugging the equipment, the user is encouraged to try one or more of the following corrective measures :

- Reorient the radio or TV's receiving antenna.
- Increase the distance between the device and the radio or TV.
- Use different outlets for the device and the radio or TV.

Consult the dealer or a service technician if the problem still exists.

SPECIFICATIONS

Power Source.....120V AC, 50/60Hz
Power Consumption.....13 Watts Max.
Bulb Size.....120(4.7") ~ 125mm(4.9")

PRODUCT USE STATEMENT

This equipment generates and uses radio frequency energy. It has been tested and found to comply with the limits of FCC rules.

These limits are designed to provide reasonable protection against radio or TV interference in a residential area.

LIGHT FLOWER

Owner's Manual
Please read before using this equipment.



INTRODUCTION

Your new LIGHT FLOWER safely captures the mysterious power of lightning in a safe glass chamber. The brilliant light show provides hours of fascination and entertainment for you and your friends.

Features :

- Stunning lightning displays appear in the safe, enclosed chamber.
- Creates beautifully sculpted lightning formations when you touch the chamber's surface.
- Responds to your voice or music.

HOW DOES IT WORK?

LIGHT FLOWER uses a palette of electromagnetic, physics and chemistry to create an ever-changing art form. LIGHT FLOWER's outer glass dome contains a secret mixture of safe, rare gases that creates brilliant flashes of lightning. The inner dome radiates energy into the glass dome's atmosphere. This energy causes electrons to break loose from the gas atoms, producing more energy, which you see as light. The atmosphere's energy field affects these free electrons. Place your hand near or on the glass and you create interference which sculpts the patterns of energy.

Warning : To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.



CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of unannounced dangerous voltage within the product's enclosure.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



SETTING UP


LIGHT FLOWER's brilliant lightning patterns appear brighter in a dimly lit room, so select a location where you can lower the room light.

Caution : Some of LIGHT FLOWER's components are made of glass. Use extreme care in unpacking them to avoid breakage or injury. If the glass dome is broken, repack it and return it to the store where you purchased it. Do not plug in the LIGHT FLOWER or attempt to operate it.

OPERATION

Cautions :

- Touch the glass only with your hands. Do not touch the glass with metal objects.
- Do not leave your hands on the glass for an extended period of time. This could result in a burning sensation.
- Never attempt to remove the glass dome.



- Plug the AC power cord into any indoor standard AC wall outlet and press in the ON/OFF Switch. The LIGHT FLOWER lights.

- To set the LIGHT FLOWER to respond to your touch, press in the audio switch. Touching the glass dome with your hand will cause the lightning to be attracted to the place you touch. As you move your hand over the surface of the dome, the lightning will follow. You may feel a slight tingling from the dome. This is from the vibration of the glass and is normal.

- To set the LIGHT FLOWER to respond to your voice, music or any other sound, press the audio switch so it is in the out position. The lightning display responds to sounds.

- The dome cover can be removed for greater variety. For the brightest displays, however, you should keep the dome cover on.

CARE AND MAINTENANCE

Your LIGHT FLOWER is an example of superior design and craftsmanship. The following suggestions will help you care for it so you can enjoy it for years.

- Keep LIGHT FLOWER dry. If it does get wet, wipe it dry immediately. Liquids contain minerals that can corrode the electronic circuits.
- Use and store LIGHT FLOWER only in normal temperature environments. Temperature extremes can shorten the life of electronic devices and distort or melt plastic parts.
- Handle LIGHT FLOWER gently and carefully. Dropping it can break the glass, damage circuit boards and cases, and cause it to work improperly.