


Function Block Diagram.

AZV30 Block Diagram



- A <6MHz
- B <6MHz
- C <6MHz
- D DC
- E 35.468930MHz
- F 28.636363MHz
- G <33MHz
- H <100KHz
- J <17MHz