


MIRROR BOOMBOX

Quick Start Guide

iui DESIGN




The MINI mark and logos are registered trademarks of BMW AG. © Platform2 International Limited. All Rights Reserved.

Quick Start Guide

WWW.MIRRORBOOMBOX.COM

INFO@MIRRORBOOMBOX.COM

MIRROR BOOMBOX



1 2 3 4 5 6 7


8 9

Bluetooth

1	Volume -
2	Phone/Play/Pause/Pair
3	Volume +
4	Button LED Indicator
5	Operation LED Indicator
6	Microphone
7	Power Button
8	Aux-in
9	USB Power


Near Field Communication

1




Turn On both Speaker and NFC feature on your device

2



Tap your device on the back of the Speaker for the pairing



3



Your Device will pair and connect to the speaker automatically. Please play music on your device.



How to Connect ...





1





Switch to "On" position and Operation LED Indicator in Blue

2




Keep pressing the top of  on the touch panel as shown until Button LED Indicator flashing ,  &  with "Discovering" voice prompt

3






Search & Connect "MIRROR BOOMBOX" in your mobile device. Upon success connection, the LED Indicator stop flashing and "Your Device is Connected" voice prompt

4




Receive incoming call




Pressing the top of  on the touch panel when receive incoming call, press  again to end the call


LED Indicator



Power ON + Full Charged
→ Solid Blue



Power ON + Charging
→ Solid Purple



Power OFF + Charging
→ Solid Red

* If music is not playing and Bluetooth is not connecting for 15min., Mini Boombox will automatically go into Standby Mode to help conserve energy.
* The iOS 4.1.x is NOT using on your iDevice, or the speaker will become unstable when playing music
* Fully charged once a month.
* "0000" is the passcode if necessary during pairing.

Printed in China

IMPORTANT SAFETY INSTRUCTIONS

1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all Instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding– type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prongs are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus.
When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. Do

not place objects filled with water, such as a vase, on the apparatus.

16. The AC mains plug is used as the power disconnect device and it should remain readily accessible and operable during intended use. In order to completely disconnect the apparatus from the power, the mains plug should be completely removed from the AC outlet socket.

17. CAUTION: To reduce the risk of fire or explosion, do not expose batteries to excessive heat such as sunshine, fire or other heat sources.

18. If an apparatus is provided with a replaceable lithium battery, the following applies:

- if the battery is intended to be replaced by the USER, there shall be a warning close to the battery or in both the instructions for use and the service instructions;

- if the battery is not intended to be replaced by the USER, there shall be a warning close to the battery or in the service instructions.

This warning shall include the following or similar text:

CAUTION

Danger of explosion if battery is incorrectly replaced.

Peplace only with the same or equivalent type.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.