

SECTION 5

PHOTOGRAPHS

PHOTOS OF THE TESTED EUT

The following photos are attached:

- Photo 1. EUT, Showing A & B Units Sold As A Pair
- Photo 2. EUT, Front View
- Photo 3. EUT, Rear View
- Photo 4. EUT, Bottom View Showing Various Ports
- Photo 5. EUT, Case Opened
- Photo 6. EUT, Top View of Laser Alignment Head CPU Board
- Photo 7. EUT, Bottom View of Laser Alignment Head CPU Board
- Photo 8. EUT, Bottom View of Laser Alignment Head CPU Board (TX Board Removed)
- Photo 9. EUT, Top View of TX Board
- Photo 10. EUT, Bottom View of TX Board
- Photo 11. EUT, Laser Alignment Head CPU Board and TX Board Removed
- Photo 12. EUT, PSD Board Removed from Laser/Photosensitive Components
- Photo 13. EUT, Top View of PSD Board
- Photo 14. EUT, Bottom View of PSD Board
- Photo 15. EUT, Top View of LEMO Board
- Photo 16. EUT, Bottom View of LEMO Board
- Photo 17. EUT, Top View of Laser Driver Board
- Photo 18. EUT, Bottom View of Laser Driver Board
- Photo 19. EUT, Top View of Photosensitive Detector
- Photo 20. EUT, Bottom View of Photosensitive Detector

Photo 1. EUT, Showing A & B Units Sold As A Pair



Photo 2. EUT, Front View



Photo 3. EUT, Rear View



Photo 4. EUT, Bottom View Showing Various Ports

