

Applicant: High Tech Computer Corp

FCC ID: NM8ATHE100

Correspondence Reference Number: 33455

731 Confirmation Number: EA400485

Date of Original E-Mail: 7/25/2007

- 1) user manual says screen has landscape and portrait orientations
 - is it also possible to use 180-degree landscape and 180-degree portrait, for a total of four possible screen orientations?

Answer:

There are three modes to choose from in the device-setting page: Portrait, Landscape (right-handed) and Landscape (left-handed). However, the left-handed landscape mode is just a default function defined by Microsoft and it is not to be specified or recommended in the user manual for ATHE100. This is because ATHE100 is in the shape of landscape and the right-handed landscape mode is actually good for both right-handed and left-handed people to use.





Landscape -180-degree




Portrait

2)if there are only two screen orientations, based on for example user manual sec. 1.1 diagram of front face of display, please submit sketch(s) showing directions of landscape and portrait orientations, and also including sketch marks to show relative antenna size and positions

Answer:

Note: Internal antenna size and position is marked with the red square. Actually the antenna is located at the back.

(1) Landscape orientation:



(2) Portrait orientation:

